





































Mounting instructions: Roof shutter AS31















For spareparts, visit our webshop on: www.AluShutter.eu

AluShutter®

AluShutter is not responsible for damage, when not properly mounted the Rollershutter and their parts, misuse of the roller shutter, incomplete or incorrect instructions.